



PRODUCT PRICE LIST

For unlisted items and bulk pricing, call us at (703) 471-4200

Three levels of TAT are available. Although handling times will vary depending on the test additional surcharges may apply for expedited services.
Routine TAT - 1 x Routine Price; Rush - 2 x Routine Price; Emergency - 3 x Routine Price

Last Updated: March 2021

Test Number	Analysis	Matrix	Method	Routine TAT
Bacterial Analyses				
T-1025	Acid Producing Bacteria (APB)	Water	BART (HACH)	10 days
T-1025	Denitrifying Bacteria (DB)	Water	BART (HACH)	10 days
T-1037	Enterococcus	Water	Enterolert (P/A)	2 days
T-1025	Iron-Related Bacteria (IRB)	Water	BART (HACH)	10 days
T-1025	Nitrifying Bacteria (NB)	Water	BART (HACH)	10 days
T-1025	Pseudomonas	Water	BART (HACH)	10 days
T-1067	Pseudomonas aeruginosa	Water	Pseudalert (P/A)	2 days
T-1025	Slime-Forming Bacteria (SFB)	Water	BART (HACH)	10 days
T-1025	Sulfate-Reducing Bacteria (SRB)	Water	BART (HACH)	10 days
T-1002	Total Coliforms / E. coli	Water, wipe	Colilert (P/A)	2 days
T-1021	Total Coliforms / E. coli	Water	Colilert (MPN)	2 days
T-1092	Heterotrophic Plate Count (HPC)	Water	SimPlate (MPN)	2 - 3 days
T-1008	Heterotrophic Plate Count (HPC)	Air, Bulk, Water, Wipe	Culture (w/o IDs)	3 - 5 days
T-1008	Heterotrophic Plate Count (HPC)	Air, Water	Culture (w/ IDs)	3 - 5 days
T-1008	Heterotrophic Plate Count (HPC)	Wipe	Culture (w/ IDs)	3 - 5 days
T-1008	Heterotrophic Plate Count (HPC)	Bulk	Culture (w/ IDs)	3 - 5 days
T-1012	Heterotrophic Plate Count (Anaerobic)	Water	Culture (w/o IDs)	3 - 5 days
Fungal Analyses				
T-1000	Total Spore Count	Air	Direct Microscopy	3 - 5 days
T-1001	Total Spore Count (Tape-Lift)	Wipe, Bulk	Direct Microscopy	3 - 5 days
T-1004	Total Fungal Plate Count	Air, Bulk, Water, Wipe	Culture (w/o IDs)	3 - 5 days
T-1004	Total Fungal Plate Count	Air, Water	Culture (w/ IDs)	3 - 5 days
T-1004	Total Fungal Plate Count	Wipe	Culture (w/ IDs)	3 - 5 days
T-1004	Total Fungal Count w/ IDs	Bulk	Culture (w/ IDs)	5 - 7 days
Legionella Analyses				
T-1065	Legionella Culture	Water	ISO 11731:2017	7 - 10 days
T-1061	Legionella pneumophila	Water	Legiolert (IDEXX)	7 days
T-1094	Legionella pneumophila - qPCR	Water	ISO 12869:2019	2 days
Other Analyses				
T-1025	Blue-Green Algae Screen (BGA)	Water	BART (HACH)	10 days
PA-1002	Biological Assessment	Air, Bulk, Water, Wipe	Culture (Fungi & Bacteria)	5 - 7 days
T-1082	COVID-19 (PCR)	Wipe	SARS-CoV-2 RNA (P/A)	2 days
T-1004 / T-1000	Fungal Profile	Air, Bulk, Water, Wipe	Culture & Total Spore Count	5 - 7 days