



PRODUCT LIST

For unlisted items and bulk pricing, call us at (703) 471-4200

Three levels of TAT are available. Although handling times will vary depending on the test additional surcharges may apply for expedited services. Competitive rates offered for special projects based on volume. Need supplies? Media & supplies provided free of charge with purchase.
Routine TAT - 1 x Routine Price; Rush - 2 x Routine Price; Emergency - 3 x Routine Price

Last Updated: May 2022

Test Number	Analysis	Matrix	Test Method	Routine TAT
Bacterial Analyses				
T-1025	Acid Producing Bacteria (APB)	Water	BART (HACH)	10 days
T-1025	Denitrifying Bacteria (DB)	Water	BART (HACH)	10 days
T-1037	<i>Enterococcus</i> sp.	Water	Enterolert (P/A)	2 days
T-1002	Fecal Coliforms / <i>E. coli</i>	Water, Wipe	Colilert (P/A)	2 days
T-1021	Fecal Coliforms / <i>E. coli</i>	Water, Wipe	Colilert (MPN)	2 days
T-1092	Heterotrophic Plate Count (HPC)	Water	SimPlate (MPN) (C)	2 - 3 days
T-1008	Heterotrophic Plate Count (w/o IDs)	Air, Bulk, Water, Wipe	Culture (CFU)	3 - 5 days
T-1008	Heterotrophic Plate Count (w/ IDs)	Air, Bulk, Water, Wipe	Culture (CFU)	3 - 5 days
T-1012	Heterotrophic Plate Count (Anaerobic)	Water	Culture (CFU)	3 - 5 days
T-1025	Iron-Related Bacteria (IRB)	Water	BART (HACH)	10 days
T-1025	Nitrifying Bacteria (NB)	Water	BART (HACH)	10 days
T-1025	<i>Pseudomonas</i> sp.	Water	BART (HACH)	10 days
T-1067	<i>Pseudomonas aeruginosa</i>	Water	Pseudalert (P/A)	2 days
T-1068	<i>Pseudomonas aeruginosa</i>	Water	Pseudalert (MPN)	2 days
T-1025	Slime-Forming Bacteria (SFB)	Water	BART (HACH)	10 days
T-1025	Sulfate-Reducing Bacteria (SRB)	Water	BART (HACH)	10 days
T-1002	Total Coliforms / <i>E. coli</i>	Water, Wipe	Colilert (P/A) (C)	2 days
T-1021	Total Coliforms / <i>E. coli</i>	Water, Wipe	Colilert (MPN)	2 days
Fungal Analyses				
T-1004	Total Fungal Plate Count (w/o IDs)	Air, Bulk, Water, Wipe	Culture (CFU)	3 - 5 days
T-1004	Total Fungal Plate Count w/ IDs	Air, Bulk, Water, Wipe	Culture (CFU)	3 - 5 days
T-1000	Total Spore Count	Air	Direct Exam (A)	3 - 5 days
T-1001	Total Spore Count (biotape)	Bulk, Wipe	Direct Exam (A)	3 - 5 days
Legionella Analyses				
T-1065	<i>Legionella</i> sp. (NYS ELAP)	Water	ISO 11731:2017(E) (A)	7 - 10 days
T-1065	<i>Legionella</i> sp.	Water	CDC ELITE (C)	7 - 10 days
T-1061	<i>Legionella pneumophila</i>	Water	IDEXX Legiolert (MPN)	7 days
T-1094	<i>Legionella pneumophila</i> - qPCR	Water	ISO 12869:2019	2 days *
Other Analyses				
T-1025	Blue-Green Algae Screen (BGA)	Water	BART (HACH)	10 days
PA-1002	Biological Assessment (Fungi & Bacteria)	Air, Bulk, Water, Wipe	Culture (CFU)	5 - 7 days
T-1004 / T-1000	Fungal Profile	Air, Bulk, Water, Wipe	Culture & Direct Exam	5 - 7 days
T-1096	Soot & Ash Profile	Wipe	Direct Exam	3 - 5 days

(A) - Accredited Method; (C) - Certified Method, CFU - Colony Forming Units; MPN - Most Probable Number; P/A - Presence/Absence; * - contact laboratory prior to submitting samples